



LuminoLite

LuminoLite CREE XPE Headlamp Instruction Manual

How to replace batteries

1. Lift the clasp on top of the headlamp and open the battery case.
2. Insert the batteries with polarity in correct position. As indicated inside the case.
3. Close the battery case fully until you hear a click.



How to adjust angle of light

- Hold the headlamp and tilt it downwards up to 45 degrees.



How to change light setting

White CREE: Press the left button on top of the headlamp (with the light facing away from you). The first press will activate the main beam (up to 160 lumens). The second press will activate the lower light setting (up to 40 lumens). The third press will activate the strobe setting. One final press will turn the light off.

Note: If white light doesn't turn off ensure that the red LEDs are turned off first.

Red LEDs: Press the right button to turn the red LEDs on. Press again to activate the strobe setting. Press again to turn the red LEDs off.

Attention: Avoid staring at LEDs or shining into a person's eyes. Bright lights can damage your eyes or the eyes of those around you. RISK OF RETINAL DAMAGE.

Battery life and safety:

Battery life depends on the brand and freshness of batteries as well as the light setting used. Batteries may last up to 83 hours on the main beam and up to 135 hours on the lower brightness setting.

Batteries:

- 1) Use new alkaline AAA-Cell batteries with 1.5V rating for best results.
- 1) Do not mix old and new batteries.
- 2) Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
- 3) Do not dispose of batteries in fire.
- 4) Batteries should be recycled or disposed of as per state and local guidelines.
- 5) Install batteries with polarity in correct position.
- 6) If battery has leaking fluids, do not touch fluids, wash hands immediately.

IPX6 rated: This headlamp is rain proof but cannot be submerged into water.

Note: Dry after use in wet environment.

Troubleshooting

If headlamp does not work/turn off or malfunctions:

- Ensure that the batteries are inserted correctly.
- Replace with new batteries.
- Check the contacts and connections are clean.
- Try pressing the switch several times.

Contact support@luminolite.com if you require assistance.

Safety Information

A responsible adult must supervise use by children under the age of 13.

To reduce the risk of strangulation, do not place the headlamp straps around your neck.

Always inspect your headlamp for proper operation prior to use, carry a second light and spare batteries. Avoid staring at LEDs or shining into a person's eyes. Bright lights can damage your eyes or the eyes of those around you. RISK OF RETINAL DAMAGE.

This is not a toy and not intended for young children.

IMPORTANT

Avoid proximity to heat sources such as fires, radiators etc as this may cause damage.

Avoid dropping the headlamp as this may cause damage.

Follow all instructions carefully. Any modifications of this product will void the warranty. Misuse of the headlamp may cause the user harm.

LuminoLite is not responsible for the consequences, whether direct, indirect, or accidental, or for any other type of damage arising or resulting from the use of its products. You are responsible for your actions and activities and for any consequences that may result from them.